

LIST No. 115/2.

June, 1967.

### SPARE PARTS LIST

FOR TYPE 302 RIGID AND TYPES 504 AND 510 REMOTE FLOAT CHAMBERS

| COMPONENT                         | RIGID          | TYPE 302<br>RIGID | REMOTE      | TYPE 504<br>REMOTE |             | REMOTE             |
|-----------------------------------|----------------|-------------------|-------------|--------------------|-------------|--------------------|
|                                   | PART NO.       | PART No.          | PART No.    | PART No.           | PART No.    | PART NO.           |
| Float Chamber Complete            | 302/1          | 302/10            | 302/18      | 504/1              | 504/2       | 510/1              |
| Float Chamber Body only           | 302/001        | 302/001           | 302/015     | 504/001            | 504/001     | 510/001            |
| Float Chamber Cover complete      | 302/002        | 302/002           | 302/002     | 504/008            | 504/008     | 510/003            |
| Float Chamber Cover Washer        |                | -                 | 12/         | -                  | ****        | 510/004            |
| Cover Fixing Screws               | 302/009        | 302/009           | 302/009     | 302/009            | 302/009     | 302/009            |
| Fickler                           | 302/010        | 302/010           | 302/010     | 504/007            | 504/007     | 510/023            |
| Fickler Spring                    | 14/032         | 14/032            | 14/032      | 14/032             | 14/032      | 14/032             |
| Fickler Cotter                    | 14/033         | 14/033            | 14/033      | 14/033             | 14/033      | 14/033             |
| lickler Washer                    | 14/189         | 14/189            | 14/189      | 14/189             | 14/189      | 14/189             |
| Float                             | 302/004        | _                 | _           | 504/005            | 504/005     |                    |
| Float See note                    | 302/032        | _                 | _           |                    | -           | 510/009            |
| Float                             | 302/042        | 302/042           | 302/042     | _                  | _           | 0.0,000            |
| Float Needle below re             | 14/320         | _                 | -           | _                  | _           | 510/006            |
| Float Needle                      | 302/035        | _                 |             |                    |             | 010/000            |
| Float Needle modifica-            | 302/044        | 302/044           | 302/044     | 302/044            | 302/044     |                    |
| Base Plug and Guide               | 14/321-2       | -                 | -           | 002/011            | 302/011     |                    |
| Base Plug and Guide tion *        | 14/322-302/036 | _                 | _           |                    | _           |                    |
| Base Plug and Guide               | 302/045-6      | 302/045-6         | 302/045-6   |                    | _           |                    |
| Base Plug Washer                  | 14/252         | 14/252            | 14/252      |                    |             |                    |
| Sanjo (see illustrations, page 3) | as required    | as required       | 14/250      | as required        | as required | as required        |
| Banjo Nut or Bolt                 | 14/255         | 14/255            | 14/255      | 302/043            | 302/043     | 510/011            |
| Banjo Washers                     | 14/275         | 14/275            | 14/275      | 14/275             | 14/275      | 510/012            |
| Petrol Union Nuts                 | 14/042         | 14/042            | 14/042      | 14/042             | 14/042      | 14/042             |
| Petrol Union Nipples              | 14/041         | 14/041            | 14/041      | 14/041             | 14/041      | 14/041             |
| Plug Screw                        | 14/232         | 14/232            | 12/011      | 14/041             | 14/041      | 510/019            |
| Plug Screw Washer                 | 14/241         | 14/241            | _           | 1                  |             | 14/336             |
| Float Chamber Connection          |                | 14/241            | 302/071     | 14/219             | 302/070     | 14/219             |
| Float Chamber Con't'n Washer      | _              |                   | 14/037      | 14/336             | 14/336      | 14/336             |
| Banjo Connection (for M/ch.)      |                |                   | 302/057     | 14/330             | 14/350      | 14/330             |
| Banjo Connection Washer           | -              |                   | 14/336      |                    |             |                    |
| Banjo Nut (Outlet)                | _              |                   | 302/056     |                    | _           | _                  |
| Base Plug and Guide (Excelsior)   | 302/069-046    | 302/069-046       | 302/069-046 |                    |             | _                  |
| Needle Seating Washer             | 002/003-040    | 302/003-010       | 302/008-046 |                    |             |                    |
| T M. C M                          | _              | _                 |             | _                  | _           | 14/047             |
| Float Hinge Spindle Washer        | 1              | _                 |             |                    | _           | 510/005            |
| Float Hinge Spindle complete      |                |                   |             |                    |             | 116/162            |
| Banjo Bolt Washer                 | _              |                   | _           | _                  |             | 510/018<br>178/035 |

<sup>\*</sup>Original part numbers 302/004, 14/320, 14/321-2, were modified to 302/032, 302/035, 14/322-302/036 since when a further modification was made, i.e., 302/042, 302/044, 302/045-6.

GUARANTEE.—The Company take all possible reasonable care in the manufacture and the quality of their products. Purchasers are informed that, any part proved to be defective in manufacture or quality, and returned to the works within six months of its purchase new, will be replaced. The Campany must respectfully point out however, that its responsibility and that of its agents, stockists and dealers, is limited to this Gueraniee, and that they cannot, under any circumstances, be held responsible for any loss or for any contingent or resulting liability arising through any defect. These conditions of sale and use also apply when the Company's products form part of the original equipment of machines purchased new.

## AMAL LTD., HOLDFORD ROAD, WITTON, BIRMINGHAM 6, ENGLAND


Phone: 021 - 356 4801 Telegrams: "AMALCARB, PHONE, BIRMINGHAM" Telex: Chamcom Bham 338024 Prefix all messages "Amal"

We suggest that parts prior to the last modification should be replaced as an assembly so bringing the float chamber to the latest setting.

June, 1967.

LIST No. 115/2.

## Float Chambers



PAGE THREE



June, 1967.

LIST No. 115/2 (Issue No. 6)

# Type G.P.2 RACING CARBURETTER (With TYPE 302 RIGID & TYPES 504 & 510 REMOTE FLOAT CHAMBERS)

| Component                           |          |        |     | For<br>T15GP2               | For<br>T10GP2                                 | For<br>T5GP2    | For<br>T3GF2 |
|-------------------------------------|----------|--------|-----|-----------------------------|---|-----------------|--------------|
|                                     | -10 -513 |        | _   | Specify                     | Specify                                       | Specify         | Specify      |
| Mixing Chamber Body                 |          |        | 100 | Engine                      | Engine  | Engine          | Engine       |
| straing chamber body                | +.*      |        | 4.4 | Details                     | Details                                       | Details         | Details      |
| Mixing Chamber Top                  |          |        |     | 316/097                     | 316/045                                       | 316/049         | 316/414      |
|                                     | 0,00     | 21     | 717 | 2 4 2 2 3 1 0 1 1 1 1 1 1 1 | AV 65 / 14 / 10 / 10 / 10 / 10 / 10 / 10 / 10 | 316/050         | 316/412      |
| Mixing Chamber Cap                  | Con      | * +    | *:* | 316/103                     | 316/046                                       | 32.00 March 200 | 27271        |
| Lock Spring for Mixing Chamber      |          | * "    | 6.9 | 316/098                     | 316/126                                       | 316/048         | 316/402      |
| Adjuster for Throttle Cable         | **       | **     | *10 | 316/159                     | 316/159                                       | 316/159         | 316/159      |
| Lock Nut for ditto                  |          |        | 4.4 | 3369                        | 3369  | 3369            | 3369         |
| Throttle Cable Adjuster Sheath      |          |        |     | 316/083                     | 316/083                                       | 316/083         | 316/083      |
| Chrottle Valve (Standard)           | · ·      |        |     | 316/104                     | 316/010                                       | 316/020         | 316/413      |
| Throttle Valve, opposite Standard   |          |        |     | 316/185                     | 316/013                                       | 316/189         | F100.4       |
| Throttle Valve Screwed Nipple       |          |        |     | 5/204                       | 5/204   | 5/204           | 5/204        |
| Throttle Valve Spring               |          |        |     | 175/308                     | 316/458                                       | 316/459         | 316/466      |
| Jet Needle (Standard)               |          |        | • • | 316/007                     | 316/007                                       | 316/146         | 316/465      |
| Jet Needle (Weak)                   |          |        |     | 316/030                     | 316/030                                       | 316/029         | 316/408      |
| Jet Needle Clip                     |          |        | • • | 316/021                     | 316/021                                       | 316/021         | 316/021      |
| et Needle Clip Screw                |          |        |     | 316/015                     | 316/015                                       | 316/015         | 316/015      |
| Choke Adaptor (Please state bore    | size)    |        |     | Not normally s              | upplied separat                               | cly from M/c. b |              |
| Choke Adaptor Washer                |          |        |     | 316/100                     | 316/005                                       | 316/025         | 316/462      |
| Choke Adaptor Securing Screws       |          |        |     | 316/489                     | 316/489                                       | 316/489         | 316/489      |
| Spray Tube                          |          |        |     | 316/067                     | 316/067                                       | 316/144         | 316/144      |
| Air Tube (Please state bore size wl | hen orde | ering) |     | Not normally s              | upplied separat                               | ely from M/c. b | ody          |
| Air Tube Lock Ring                  |          |        |     | 175/115                     | 175/119                                       | 175/371         | 316/411      |
| Main Jet                            |          |        |     | 376/100                     | 376/100                                       | 376/100         | 376/100      |
| Jet Holder                          |          |        |     | 15/625                      | 15/625  | 316/027         | 316/027      |
| et Holder Plug Screw                |          |        |     | 3348                        | 3348  | 3348            | 316/028      |
| et Holder Plug Screw                |          |        |     |                             | 185/282                                       | 316/028         |              |
| Needle Jet                          |          |        |     | 316/065                     | 316/065                                       | 316/065         | 316/065      |
| Air Valve Cable Adjuster            |          |        |     | 2626                        | 2626  | 2626            | 2626         |
| Lock Nut for ditto                  |          |        |     | 2627                        | 2627  | 2627            | 2627         |
| Air Barrel Top                      |          |        |     | 2507                        | 2507  | 2507            | 2507         |
| Air Barrel Plug Screw               |          |        |     | _                           | -   | _               | 185/280      |
| Air Valve                           |          |        |     | 2502                        | 2502  | 2502            | 2502         |
| Air Valve Spring                    |          |        |     | 2558                        | 2558  | 2558            | 2558         |
| Air Valve Nipple Holder             |          |        |     | 2503                        | 2503  | 2503            | 2503         |
| Air Valve Nipple                    |          |        |     | 2629                        | 2629  | 2629            | 2629         |
| Air Jet                             |          |        |     | 316/052                     | 316/052                                       | 316/052         | 316/052      |
| Air Jet Plug Screw                  |          |        |     | 316/456                     | 316/456                                       | 316/456         | 316/456      |
| Air Jet Plug Screw Washer           |          |        |     | 38/023                      | 38/023  | 38/023          | 38/023       |
| **** * * *                          |          |        |     | 376/076                     | 376/076                                       | 376/076         | 376/076      |
| _                                   |          |        |     | 316/494                     | 316/494                                       | 316/494         | 316/494      |
| Pilot Jet Cover Nut                 |          |        |     | 116/162                     | 116/162                                       | 116/162         | 116/162      |
| Pilot Cover Nut Washer              |          |        | • • |                             |   |                 | ,            |
| Pilot Air Adjuster                  |          |        | • • | 332/017                     | 332/017                                       | 332/017         | 332/017      |
| Pilot Plug Screws                   |          |        | • • | 2403                        | 2403  | 2403            | 2403         |
| Pilot Air Adjuster Locknut          |          |        |     | 332/020                     | 332/020                                       | 332/020         | 332/020      |
| Pilot Air Connection                |          |        | • • | 316/490                     | 316/490                                       | 316/490         | 316/490      |
| Banjo Connection for Remote Fl      | oat Cha  | mber   |     | 14/218                      | 14/218  | 14/218          | 14/218       |
| Banjo Washer                        |          |        |     | 36/006                      | 36/006  | 36/006          | 36/006       |
| Outlet Clip                         |          |        |     | 27/073                      | 27/072  | 316/421         | 316/421      |
| Outlet Clip Screw                   |          |        |     | 1962                        | 1962  | 316/422         | 316/422      |
| Jet Key                             |          |        |     | 244/1397                    | 244/1397                                      | 244/1397        | 244/139      |

When twin carburetters fitted this component is 175/395 for Type 15. 316/406 for Type 10, and 175/396 for Type 5. \*These parts are not normally supplied separately as they are machined in position with the mixing chamber body.


#### ROAD, WITTON, AMAL LTD., HOLDFORD BIRMINGHAM 6, ENGLAND

Phone: 021 - 356 4801 Telegrams: "AMALCARB, PHONE, BIRMINGHAM" Telex: Chamcom Bham 338024
Prefix all messages "Amal"

LIST No. 115/2

June, 1967.

## G.P.2 Mixing Chamber



PAGE TWO